

TO FIT SIZE CHART

*Measurements refer to body size, not garment dimensions



R127X - LANCE BODYWARMER

	S	M	L	XL	2XL	3XL
Full chest in inches*	38	41	44	48	52	56
Full chest in cm*	96,52	104,14	111,76	121,92	132,08	142,24
German clothing size (men)	48	50	54	58	62	66

HOW TO MEASURE CHEST: Place the tape measure across the back, underneath the arms and then across the fullest part of the chest.

1 Inch = 2,54 cm